Router and Switch Housekeeping V1.3

By Passing a Password on a Router

- 1. Power router off, wait 10secs, then power on.
- 2. You can choose one of following options::

```
Option 1 - Run JAVA Console: Click SEND BREAK Button
```

Option 2 - Run NATIVE Console: Use Ctrl -] to take you to console then type send break

The Router will enter rommon mode: rommon 1>

3. Change the Configuration register to 0x2142 (this will bypass the existing startup-config):

rommon 1> confreg 0x2142

4. Once back at the rommon prompt, type **reset.** The router will reboot:

rommon 2> reset

5. Once the Router is booted, you will be asked the following question, answer no:

Would you like to enter the initial configuration dialog? [yes/no]: no

6. Go to the Privileged Executive mode by typing **enable** at the Router> prompt:

Router> enable

Router#

7. You can now start configuring the router:

Router# config t

(Note: If instead you want to use the startup-config then Router# copy startup-config running-config)

By Passing a Password on a Switch

- 1. Power switch off, wait 10secs, then power on -> while pushing Mode Button until SYS LED starts flashing.
- 2. The Switch enters the following mode

Switch:

3. In Switch: (Enter) flash_init

dir flash:

delete flash:config.text

reset

Cleaning a Router

1. Erase the Startup configuration.

Router# erase startup-config

Erasing the nvram filesystem will remove all configuration files! Continue? [confirm] <Enter>

2. Reboot the Router.

Router# reload

Proceed with reload? [confirm] <Enter>

(Answer NO to any request to save the current running-config)

Cleaning a Switch

1. Erase the Startup configuration.

Router# erase startup-config

Erasing the nvram filesystem will remove all configuration files! Continue? [confirm] <Enter>

2. Erase the VLAN information that is kept in flash.

Switch# delete vlan.dat

3. If any of the following questions are prompted for confirmation, press <Enter>.

Delete filename [vlan.dat]?

Delete flash:vlan.dat? [confirm] <Enter>

(Before confirming - check that you are not erasing the IOS Image)

4. Reboot the Switch.

Switch# reload

Proceed with reload? [confirm] <Enter>

(Answer NO to any request to save the current running-config)